

Marshmallow Shooter™ Item # 1100 “Tips & Tricks”

FOR AGES 8 AND UP. €€

MFC takes pride in making quality, fun toys that comply with U.S. and international safety standards.

As fun and Novel as marshmallows are, they do have limitations as a projectile. Since marshmallows consist of only sugar and air, heat and moisture can create problems with marshmallows melting in the magazine. This problem is especially apparent in the hot summer months. There are a couple of things you can do to circumvent or at least delay the reoccurrence of marshmallow meltdown.

1. Certain marshmallow brands work better than others. Of course we recommend our *Marshmallowville Marshmallows™* which have been specially formulated for peak performance.
2. Stale marshmallows have tougher skins and resist tearing better. We get better results from bags of marshmallows that have been opened for an hour. Storing the marshmallows at room temperature is best.
3. Cleaning is required after marshmallows melt in the shooter. The goo can be easily washed out with hot tap water or a cycle through the top rack of the dishwasher. Be careful not to scratch the internal surfaces with anything sharp. We have designed the Marshmallow Shooter™ so that parts susceptible to melted marshmallows can be easily removed for cleaning. After cleaning, make sure that all parts are completely dry. Any moisture will accelerate the melting of marshmallows.
4. During the loading cycle the marshmallow can be exposed to a considerable amount of vacuum. The vacuum causes the marshmallow to expand before it is loaded into the chamber. If the expansion is too great, the skin of the marshmallow will crack exposing the sticky center. This will also cause the Marshmallow Shooter™ to jam. To avert this, the front grip should be pulled to the rear with just enough force to chamber the marshmallow. This is also the technique if you only want to shoot single marshmallows instead of multiple.

The Marshmallow Shooter™ is a very durable toy with an endless supply of cheap ammo. It should last for many years with proper maintenance. These 4 tips should help you get more enjoyment from your new toy.

Marshmallow Fun Company wants every customer to be a happy one:

For support or questions call toll-free 877.894.6073.



Marshmallow Fun Company
500 Orchard Pond Road, Tallahassee, Florida 32312
Toll-Free: 877.894.6073 Fax: 850.894.6073
www.marshmallowshooter.com

PATENT #: US 6,904,901 B2 © 2006 MARSHMALLOW FUN COMPANY